

◆ To prevent foreign objects from entering the pen heater, install the included strainer (MS-6) in the suction pipe. the included strainer (MS-6) in the suction-side piping before use.

※The photo below shows the air supply tube for the pen heater ($\phi 6 \times \phi 4 \times$ approx. 1r
This is an example of cutting the tube and installing the Strainer MS-6 in the middle



Regularly inspect the metal mesh inside the strainer and clean it with acetone. If the mesh becomes clogged, the pen heater will overheat abnormally.

◆ To prevent foreign objects from entering the pen heater, install the included strainer (MS-6) in the suction pipe. the included strainer (MS-6) in the suction-side piping before use.

*The photo below shows the pen heater's air supply tube ($\phi 6 \times \phi 4 \times$ approx. 1m, ma
An example showing the wire mesh cut and fitted with a Strainer MS-6 in the middle



Regularly inspect the metal mesh inside the strainer and clean it with acetone. If the mesh becomes clogged, the pen heater will overheat abnormally.